



## PRODUCT CAUTIONS

- ⚠ **CAUTION:** If any tags or bands on the nozzle are worn or damaged and cannot be easily read, they should be replaced.
- ⚠ **CAUTION:** Do not over tighten the nozzle onto the monitor.
- ⚠ **CAUTION:** The nozzle is configured for optimum performance. Do not alter in any manner.
- ⚠ **CAUTION:** Your nozzle should be inspected prior and after each use, to ensure it is in good operating condition. Periodically, an unanticipated incident may occur where the nozzle is used in a manner that is inconsistent with standard operating practices and those listed in IFSTA. A partial list of potential misuses follows:

- Operating above maximum rated pressure and flow.
- Not draining, and allowing water to freeze inside the nozzle.
- Dropping the nozzle from a height where damage is incurred.
- Prolonged exposure to temperatures above +130 degrees F, or below -25 degrees F,
- Operating in a corrosive environment.
- Other misuse that might be unique to your specific fire fighting environment.

There are many “tell tale” signs that indicate nozzle repair is in order, such as:

- Controls that are either inoperable or difficult to operate.
- Excessive wear.
- Poor discharge performance.
- Water leaks.

If any of the above situations are encountered, the nozzle should be taken out of service and repaired, plus tested by qualified nozzle technicians, prior to placing it back in service.

## OPERATING INSTRUCTIONS

- To change the spray angle, push the toggle switch to either SS (straight stream) or fog.
- To change the flow setting, you must shut off the flow, adjust the spray pattern past fog until it stops, then manually push the baffle head in and rotate it until the roll pin aligns with the desired flow setting.
- To flush the nozzle push the toggle switch towards the fog position until it stops. This gives you the maximum orifice for clearing small debris.

## MAINTENANCE

- Under normal conditions, periodically flushing the nozzle with clean water and cleaning grit and dirt from around exterior moving parts will allow the nozzle to operate as designed.
- Over time the O-Rings may need to be replaced. This can be accomplished by purchasing the appropriate O Rings shown on the service parts list. Use qualified maintenance mechanics or return the nozzle to Akron Brass for repair.



PHONE: 330.264.5678 or 800.228.1161 | FAX: 330.264.2944 or 800.531.7335 | [www.akronbrass.com](http://www.akronbrass.com)

REVISED: 5/10

WARRANTY AND DISCLAIMER: We warrant Akron Brass products for a period of five (5) years after purchase against defects in materials or workmanship. Akron Brass will repair or replace product which fails to satisfy this warranty. Repair or replacement shall be at the discretion of Akron Brass. Products must be promptly returned to Akron Brass for warranty service.

We will not be responsible for: wear and tear; any improper installation, use, maintenance or storage; negligence of the owner or user; repair or modification after delivery; damage; failure to follow our instructions or recommendations; or anything else beyond our control. WE MAKE NO WARRANTIES, EXPRESS OR IMPLIED, OTHER THAN THOSE INCLUDED IN THIS WARRANTY STATEMENT, AND WE DISCLAIM ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE. Further, we will not be responsible for any consequential, incidental or indirect damages (including, but not limited to, any loss of profits) from any cause whatsoever. No person has authority to change this warranty.

© Premier Farnell Corporation. 2010 All rights reserved. No portion of this can be reproduced without the express written consent of Premier Farnell Corporation.

**A Premier Farnell Company**