



Open and Closing the Waku Ladder

How to use as a stepladder

1. Place ladder in front of you in stored position.
2. Disengage the spring loaded hinge locks by pulling them out fully from the side of the ladder
3. Extend one side of the ladder beyond the A-frame position until you hear FIRST CLICK indicating that the first stage of the hinge locking mechanism has been activated
4. Lower same side of the ladder until you hear SECOND CLICK and check to ensure that the spring loaded hinge locks are fully secured before use.

If extended height is required

1. Place ladder in front of you in stored position.
2. Disengage the spring loaded hinge locks by pulling them out fully from the side of the ladder
3. Pull the four spring loaded stile locks out of the rung holes of the inner section and rest them on the side of the outer ladder section
4. Raise the inner ladder up to the desired height, support and level rungs with one hand
5. Reinsert all four stile locks with the other hand at desired height, and check to ensure that the locking devices are fully secured before proceeding.
6. Extend one side of the ladder beyond the A-frame position until you hear FIRST CLICK indicating that the first stage of the hinge locking mechanism has been activated
7. Lower same side of the ladder until you hear SECOND CLICK and check to ensure that the spring loaded hinge locks are fully secured before use.

Return ladder from stepladder position to storage position.

1. Disengage the spring loaded stile locks by pulling them out fully from the side of the ladder
2. Working from side to side, slowly lower the inner ladder by releasing the
3. Close ladder to A-frame position
4. Open all four Stile locks with the other hand.
5. Get secure hold of inner section and let it slide back rung by rung into storage position.
6. Lock all four Stile locks and both hinge locks securely

How to use as an extension ladder

1. Place ladder in front of you in storage position.
2. Disengage the spring loaded hinge locks by pulling them out fully from the side of the ladder
3. Rotate either side of the ladder until the hinge locks snap FULLY into their locked positions, checking to ensure that the locking devices are fully secured
4. On the upper section of the ladder, pull out the spring loaded Stile locks out of the rung holes of the inner section and rest them on the side of the outer ladder section
5. Grasp the outer ladder, walk backwards, allowing the ladder to telescope to the desired height. If more height is required, extend lower half of ladder in the same manner
6. Once desired height is reached, make sure ALL locks are securely closed.
7. Place ladder against supporting wall at an angle of 70 degrees.